

Fool Proof Application Instructions:

Application:

Press Time: 4-8
Seconds

Temperature: 360°F

Pressure: Firm
Peel: Warm

Notes:

Preheat Platen:

Prior to beginning, press empty pad for 3 cycles of 15 seconds. Failure to preheat pad will cause insufficient heat and will damage first 3 transfers.

Care Instruction:

We recommend to machine wash in cold water. Use a mild detergent and **DO NOT** USE any aggressive or bleaching agents. Tumble dry on low heat. **DO NOT** iron transfer.

HEAT TRANSFER WAREHOUSE

2201 12th St. N

Unit F

Fargo, ND 58102

Phone: 701-356-3160

Fax: 701-356-3162



www.heattransferwarehouse.com

Step By Step:

Step 1: Load garment:

Prior to pressing, open the bottom of the garment and slide it over the platen. Pressing one side of the item at a time will eliminate ghost images/bleed through. **WARNING:** If garment is laid on top of platen be sure to check for bleed through after pressing first garment.

Step 2: Pre-Press

Garment: Press garment (with no transfer) for 3-5 seconds to remove moisture and wrinkles.

Step 3: Position Transfer:

Place transfer in desired location, ink side down. **DO NOT cover transfer with Teflon sheet.** Do NOT place transfer on wrinkles, seams or creases in garment.

Step 4: Press Transfer:

Close heat press and press for 4-8 seconds at 360° F

Step 5: Peel Transfer:

Open heat press and peel transfer with a smooth, steady motion.