

# Inkjet Light- Premium

## Application:

**Printer:** All color inkjet printers. Recommended to print with pigment or archival ink.

**Recommended Paper Mode:** Plain Paper mode or use T-shirt transfer setting.

**Image:** Mirror Image

**Press Time:** 10 Seconds

**Temperature:** 350-360°F (185°C)

**Pressure:** Heavy

**Peel:** Hot

## Notes:

**Recommended Fabrics:**  
**White or Light colored**

**Fabrics:**  
100% Cotton  
Poly/cotton blends

**Peeling:**

Peel backing paper off while still hot.

**Care Instruction:** Wait 24 hours and machine wash before wearing. Always turn textile inside out before washing. We recommend to machine wash in cold water. You may wash in warm water (40°C). Use a mild detergent and DO NOT USE any aggressive or bleaching agents. Recommend hang drying but can tumble dry with cool or warm air setting. DO NOT USE Fabric softeners. DO NOT dry clean. When ironing we recommend turning shirt insides out and ironing the image from the back.

### Step By Step:

**Step 1:** Feed transfer paper from bypass tray (single or multi sheet)

**Step 2:** Print on coated side of the transfer paper.

**Step 3:** Print **Mirror Image**.

**Step 4:** Print in **Plain Paper mode** or **T-shirt transfer setting** (for best results use high resolution of photo quality option)

**Step 5:** Trim away the unprinted paper around your image with scissors/exacto knife.

**Step 6:** Pre-press garment for 5 seconds.

**Step 7:** Position the imaged sheet on the garment with printed side facing down.

**Step 8:** Press at 350-360°F (185°C) using **Heavy pressure** for **10 seconds**.

**Step 9:** Immediately after pressing, tug lightly at the sides of the transfer to soften the feel of the transfer.

**Step 10:** Peel backing off while still hot.

**HEAT TRANSFER WAREHOUSE**

2201 12<sup>th</sup> St. N

Unit F

Fargo, ND 58102

Phone: 701-356-3160

Fax: 701-356-3162



[www.heattransferwarehouse.com](http://www.heattransferwarehouse.com)

# Inkjet Light Premium

## **Transfer with HAND IRON:**

**Step 1:** Iron on a **hard surface**. NOT an ironing board. Place a pillow case or t-shirt between your hard surface and your garment to allow the heat to penetrate the transfer.

**Step 2:** Set iron to highest temperature. Preheat iron for **5 minutes**. DO NOT USE STEAM.

**Step 3:** Trim unimaged area of transfer paper.

**Step 4:** Position transfer image face down on garment.

**Step 5:** Step-press slowly along each side of the transfer using **firm** pressure.

**Step 6:** Hold each step press for **3-5** seconds. Make sure the iron fully overlaps ALL the edges of the transfer. Ensure corners are well pressed.

**Step 7:** Total ironing should take 90-120 seconds for an 8.5" X 11" image. Pressing time must be reduced pro-rata for smaller images to avoid overheating. (E.G. an image 50% the size of an 8.5" X 11" image requires a 60-90 second press)

**Step 8:** Peel the backing paper off while still hot.

**Step 9:** Tug opposite sides of the image to stretch and soften the feel of the transfer.

**Step 10:** Wait 24 hours and machine wash before wearing.

## **Heat Transfer Warehouse**

**2201 12<sup>th</sup> St N**

**Unit F**

**Fargo, ND**

**Phone: 1-701-356-3160**

**Fax: 1-701-356-3162**

[www.heattransferwarehouse.com](http://www.heattransferwarehouse.com)

